

Using the MIDI patch bay

The MIDI patch bay (JLCooper MSB) directs MIDI information to and from all MIDI devices in the studio. This device has 9 white buttons on the front console.

To retrieve the basic studio setup from the internal memory, press the mode button so that the PGM LED is lit. Now press the white button above the '1' two times to select memory location 11. Now the Red LEDs should look like this: 7 1 1 1 1 1 1. This indicates that device number 1 is listening to device 7. All other devices are listening to device 1. Think about this for a moment while looking at the following chart:

Number	Device
1	Computer
2	Proteus
3	Roland JD 990
4	Alesis Quadraverb
5	Roland SDE-330
6	Alesis Drum machine
7	Yamaha S80 keyboard
8	Virus C analog synthesizer

Now when you play the S80 keyboard, the computer should be able to record the MIDI performance. When the computer plays the MIDI performance, all devices on the right side of the studio should be able to respond.